

KC HiLiTES, Inc.

Mounting Instructions For Your Auxiliary Rear Fog Light Kit

Thank you for choosing KC HiLiTES for your vehicle. We take pride in building the highest quality best engineered lighting systems possible. Your satisfaction with our products is important. So if there are any questions, please feel free to call our customer service line at 800-528-0950 (7 AM to 6 PM MST).

TOOLS NEEDED.....

Drill motor
7/16" drill bits

12mm wrench
17mm wrench

Pliers
Phillips screwdriver

MOUNTING INSTRUCTIONS.....

1. This light may be mounted anywhere at the rear of the vehicle provided it does not obstruct other lighting or interfere with the exhaust.
2. If you have existing holes in the bumper, and they are located in an area that is practical for mounting, then use one of those holes. This will make your installation much faster by eliminating any necessary drilling.
3. If you do not have existing holes, then you must drill one 10mm hole (7/16" will also work) in an appropriate location under the bumper.
4. Put the bolt up through the small slot in the bracket and then up through the hole in the bumper securing it with a lock washer and nut.
5. Attach the light to the under side of the bracket and position it as desired. Secure loosely with a washer and nut. Aiming instructions are on the installation instruction sheet included in your package.