



Installation Instructions for Front Light Bar KC 7438 & 7439 2007-08 Chev/GMC HD 2500/3500

Thanks for choosing a KC HiLiTES product. We take pride in building the highest quality, best engineered systems possible. Your satisfaction with our product is important, so if you have any questions, please call our customer service line at 800-528-0950.

Parts Included:

2 - 1 ½ X 1 ½ Spacers

Installing the Bar

The new KC bar will attach to the outside of each frame rail using the two bumper bolts and one of the tow hook bolts.

1. Remove the nuts from the passenger side bumper bolts and the tow hook bolt on the outside of the frame. Push the bolts in until the ends are flush with the outside of the frame.
2. Remove the nuts and bolts from the drivers side bumper bracket and tow hook. Insert the bumper mounting bolts from the inside of the frame so they are a mirror image of the passenger side bumper mounting bolts.
3. Position the light bar so that the two upper mounting holes of the light bar align with the bumper mounting bolts and the lower mounting hole with the tow hook bolt.
4. Insert the bumper mounting bolts through the light bar and start the nuts.
5. Insert the supplied spacer between the frame and light bar and insert the tow hook bolt on both the passenger and driver side.
6. Tighten all hardware.



You're DONE! - - - - - Install your KC lights and enjoy.



IF YOU HAVE ANY PROBLEMS
OR QUESTIONS, PLEASE CALL
CUSTOMER SERVICE AT 800-528-0950