

Thank you for choosing KC HiLITES for your vehicle. We take pride in building the highest quality, best engineered lighting systems possible. Your satisfaction with our products is important. If you have any questions, please feel free to call our customer service line at 800-528-0950. **For warranty information, visit our website at www.kchilites.com**

TOOLS NEEDED

Phillips Screwdriver
5/32" or 4mm Allen Wrench

PARTS INCLUDED

2 - LED Fog Lights (1 if single)

NOTE - Some earlier models will require the removal of the plastic cover between the grill and bumper.

Go to <https://www.youtube.com/watch?v=DzPbV514ye0>

MOUNTING INSTRUCTIONS

1. You must first remove the splash guard for easy access to the fog lights. Remove four screws on the front and the two screws on the back of the splash guard and set it aside. (photos A & B) You may need a flat blade screwdriver to pop the screw retaining clips loose.
2. Locate the factory fog lights behind the bumper and remove the plug connecting the wire to the bulb. Using your finger or flat blade screwdriver, pry the locking clip up away from the bulb and pull loose.
3. Remove the four screws (photo C) holding each of the factory fog lights in place and set them aside.
4. Align each of the KC LED fog lights with the four screw holes, ensuring the locating pin (photo C) matches the hole in the light bracket. Insert screws and tighten.
5. Re-attach the factory wiring.
6. Insert a 4mm or 5/32" allen wrench in the bolt at the back of the fog light and adjust the beam to shine about half way between the low beams and the ground.
7. Re-install the splash guard.



You're Done.