



**ADVENTURE
FURTHER®**

UNIVERSAL WIRE HIDER

INSTALLATION INSTRUCTIONS

IMPORTANT:

Please read all instructions before beginning installation. These guidelines are provided in good faith to help prevent any issues arising from errors during installation. The manufacturer of this product shall not be held responsible for any user actions taken or not taken during installation. There are many details of the installation that are assumed to be general mechanical knowledge to experienced installers; which are not detailed in these instructions. These installation guidelines are intended to serve as professional recommendations and are not as a step-by-step, fail-safe installation checklist. Selection of an experienced installer is the sole responsibility of the project owner.



KIT INCLUDES:

- (1) Universal Wire Hider - 1 Meter
- (1) Alcohol Pad
- (6) 3M VHB Tape - 6" Strips

STEP BY STEP INSTALLATION INSTRUCTIONS



1. Size Your Wire Hider

After determining the desired length of the wire hider, simply cut the rubber Wire Hider with a pair of scissors or utility blade.

****Remember: Measure Twice, Cut Once.****



2. Apply 3M™ VHB™ Tape

Starting at the end of the Wire Hider. Take a 6" strip of VHB Tape and remove the 'white' tape barrier. Now firmly press the tape into the channel on the bottom of the Wire Hider. It helps to run your finger into the wire route and pinching the tape to rubber to achieve a secure bond. Repeat the step for each strip; placing the tape no more than an inch apart from the other.



3. Clean Mounting Surface

Clean surface area with provided Alcohol Pad.

****Do not use cleaning products that contain ammonia (i.e. Windex), because it will degrade the adhesive agent on tape.****



4. Mounting Wire Hider

Once the final position has been determined, simply peel back the 'red' tape barrier and slowly position the Wire Hider in place.

****Make sure a smooth surface is selected.****



5. Press & Hold

It is important to firmly Press & Hold the Wire Hider in place; it will take 30s for the VHB Tape to create a bond with the best results.



6. Hide Yo' Wire

After the Wire Hider is bonded in place, tuck the wire(s) or power cable into the wire channel. The Wire Hider accepts up to a 0.315"Ø cable or small bundle of loose wires.

**You're Done!
Adventure Further.**