



ADVENTURE  
FURTHER®

PRO-R FE BAR, 30 INCH  
POLARIS RZR PRO-R, 22+

## INSTALLATION INSTRUCTIONS

**IMPORTANT:** PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION. THESE GUIDELINES ARE PROVIDED IN GOOD FAITH TO HELP PREVENT ANY ISSUES ARISING FROM ERRORS DURING INSTALLATION. THE MANUFACTURER OF THIS PRODUCT SHALL NOT BE HELD RESPONSIBLE FOR ANY USER ACTIONS TAKEN OR NOT TAKEN DURING INSTALLATION. THERE ARE MANY DETAILS OF THE INSTALLATION THAT ARE ASSUMED TO BE GENERAL MECHANICAL KNOWLEDGE TO EXPERIENCED INSTALLERS; WHICH ARE NOT DETAILED IN THESE INSTRUCTIONS. THESE INSTALLATION GUIDELINES ARE INTENDED TO SERVE AS PROFESSIONAL RECOMMENDATIONS AND ARE NOT AS A STEP-BY-STEP, FAIL-SAFE INSTALLATION CHECKLIST. SELECTION OF AN EXPERIENCED INSTALLER IS THE SOLE RESPONSIBILITY OF THE PROJECT OWNER.

### TOOLS NEEDED:

TORX T40  
13 MM SOCKET



1 USING THE TORX T40, REMOVE THE TWO FACTORY BOLTS PER SIDE. PLACE THE BRACKET, AND REPLACE OEM BOLTS, HAND TIGHT TO ALLOW FOR ADJUSTING THE BRACKETS IF NEEDED WHILE MOUNTING THE FE BAR.



2 ASSEMBLE FE BAR TO 30" LENGTH, FOLLOW LINKER ASSEMBLY INCLUDED WITH LIGHT BAR KIT. SET THE FE BAR INTO THE BRACKETS. USING THE 13MM SOCKET OR WRENCH ADJUST AND TIGHTEN THE NUTS AT EACH END OF THE FE BAR. (ALIGNMENT TIP: MOST PEOPLE HAVE THE LIGHT POINT MORE DOWN THEN EXPECTED TO COMPENSATE FOR VEHICLE LIFT DURING ACCELERATION.)



3 TIGHTEN THE BRACKETS TO THE ROOF ONCE THE FE BAR IS IN PLACE AND THE BRACKETS ARE CENTERED SIDE TO SIDE.



4 FOLLOW WIRING DIAGRAM INCLUDED WITH LIGHT BAR INSTRUCTIONS.