



**ADVENTURE
FURTHER®**

**GRAB HANDLE
PL1
92506 | 59-00289IM**

INSTALLATION INSTRUCTIONS

IMPORTANT: Please read all instructions before beginning installation. These guidelines are provided in good faith to help prevent any issues arising from errors during installation. The manufacturer of this product shall not be held responsible for any user actions taken or not taken during installation. There are many details of the installation that are assumed to be general mechanical knowledge to experienced installers; which are not detailed in these instructions. These installation guidelines are intended to serve as professional recommendations and are not as a step-by-step, fail-safe installation checklist. Selection of an experienced installer is the sole responsibility of the project owner.



TOOLS NEEDED: METRIC ALLEN KEY SET



INSERT TWO M8 NUTS PER SIDE EXTRUSION CHANNEL (4 TOTAL). PLACE THE GRAB HANDLE IN POSITION AND LOCATE THE NUTS. START FASTENING THE INCLUDED M8 BUTTON HEAD SCREWS.

PLACE THE HANDLE IN ITS DESIRED LOCATION AND TIGHTEN HARDWARE.