



**ADVENTURE
FURTHER®**

**NMO ANTENNA MOUNT
PL1
92507 | 59-00290IM**

INSTALLATION INSTRUCTIONS

IMPORTANT: Please read all instructions before beginning installation. These guidelines are provided in good faith to help prevent any issues arising from errors during installation. The manufacturer of this product shall not be held responsible for any user actions taken or not taken during installation. There are many details of the installation that are assumed to be general mechanical knowledge to experienced installers; which are not detailed in these instructions. These installation guidelines are intended to serve as professional recommendations and are not as a step-by-step, fail-safe installation checklist. Selection of an experienced installer is the sole responsibility of the project owner.



TOOLS NEEDED: METRIC ALLEN KEY SET



THIS PRODUCT IS INTENDED TO ACCEPT AN NMO BASE STYLE ANTENNA. THE HOLE DIAMETER OF THE OPENING IS 10MM.

INSERT TWO M8 NUTS INTO SIDE EXTRUSION CHANNEL. PLACE THE ANTENNA MOUNT IN POSITION AND LOCATE THE NUTS. START FASTENING THE INCLUDED M8 BUTTON HEAD SCREWS. ONCE THE BRACKET IS IN ITS DESIRED POSITION FASTEN THE HARDWARE.