



**ADVENTURE
FURTHER®**

**CYCLONE BED MOUNT KIT
2024 & UP (GEN 5) FORD RANGER
7390 | 59-00238IM**

INSTALLATION INSTRUCTIONS

IMPORTANT: Please read all instructions before beginning installation. These guidelines are provided in good faith to help prevent any issues arising from errors during installation. The manufacturer of this product shall not be held responsible for any user actions taken or not taken during installation. There are many details of the installation that are assumed to be general mechanical knowledge to experienced installers; which are not detailed in these instructions. These installation guidelines are intended to serve as professional recommendations and are not as a step-by-step, fail-safe installation checklist. Selection of an experienced installer is the sole responsibility of the project owner.



TOOLS NEEDED: 5MM ALLEN KEY WRENCH



MOUNTING THE BRACKET IS STRAIGHT FORWARD BY PLACING THE BRACKET OVER THE TWO EXPOSED TAPPED HOLES ON THE UNDER SIDE OF THE BED RAILS. (THERE ARE 4 DIFFERENT LOCATIONS AVAILABLE, WE RECOMMEND THE TWO LOCATIONS NEAREST THE TAILGATE.)

BOLT DOWN USING THE SUPPLIED SCREWS AND WASHERS. THERE ARE A FEW DIFFERENT OPTIONS FOR WIRING.